

GLIDRS350

Wireless Mouse



Ba11



User Manual

Designed For Excellence.

www.iball.co.in

Thank you for choosing **Glidr S350 wireless mouse**. Please read the user manual carefully before operation and save this user manual for further reference.

NOTE :

- *Please charge the product with power adapter output rated voltages DC 5V.*
- Please do not attempt to disassemble this product yourself, as it will result in voiding the warranty. For expert assistance, please contact our support team at 84400 45005 or feedback@iball.co.in

To review our complete warranty terms and conditions, please click the link below

[View Warranty Policy](#)

To find your nearest authorized service center, please click the link below

[Find a Service Center](#)

Features :

- Smart Status Display
- 2.4GHz & 2 BT Modes
- 3200 DPI Switchable
- 4-Level DPI Shift
- Dynamic RGB Glow
- 7-Button Control
- Quick Desktop
- Auto Sleep Mode
- High Precision
- Type C Charging
- Built-In Rechargeable Battery

Specification :




Connectivity	: 2.4GHz + 2 x BT
Resolution	: 800 1200 1600 3200 DPI
Polling Rate	: 250Hz
Sensor	: Optical
No. of Buttons	: 7
Button life	: 3 Million Cycles
Wireless Range	: 10m (Without Obstacles)
Product Dimension	: 6.7 x 10.6 x 4.1 cm (W x D x H)
Net.Weight	: 66 g

Package Contents :

Mouse	: 1 U
-------	-------

USB Receiver	: 1 U
Type C to USB A Cable	: 1 U
QR Code Guide	: 1 U

Product Description :



Connectivity Procedure

2.4 GHz Wireless Mode:

Step 1 : Plug the Nano receiver into the PC.

Step 2 : On the rear of the mouse, press the mode switch to enter into the 2.4 GHz mode.

Step 3 : On the LED display, the 2.4 GHz indicator will blink until pairing is completed. Once paired, the 2.4 GHz indicator will remain steadily lit.

BT Mode:

Step 1 : On the rear side of the mouse, press the mode button to enter BT mode. Now press and hold the mode button for 3 secs to enter BT discovery.

Step 2 : Open the BT menu on your BT device and search for the BT name "**iBall BT 1**" for **BT1** & "**iBall BT 2**" for **BT2**.

Step 3 : On the LED display, the **BT1** or **BT2** indicator will blink until pairing is completed. Once paired, **BT1** or **BT2** the indicator will remain steadily lit.

Charging:

Connect the mouse using a Type-C charger. While charging, the LED display will show .

Note : The LED display indicates battery percentage, DPI levels and Modes.



ISO 9001:2015 Certified Company
Since 2001 | www.iball.co.in