

**IMPACT
PLUS**
PRESENTATION POINTER



User Manual

Designed For Excellence.

www.iball.co.in

Thank you for choosing **IMPACT PLUS**. Please read the user manual carefully before operation and save this user manual for further reference.

Note :

- *Please do not attempt to disassemble this product yourself, as it will result in voiding the warranty. For expert assistance, please contact our support team at 84400 45005 or feedback@iball.co.in*

To review our complete warranty terms and conditions, please click the link below

[**View Warranty Policy**](#)

To find your nearest authorized service center, please click the link below

[**Find a Service Center**](#)

Features :

- 2.4GHz RF Wireless Connectivity
- Up to 100m Laser Throw Distance
- 50m Stable Wireless Range
- Cross-Platform Device & OS Compatibility
- Adjustable 3-Level Red LASER Pointer
- Type-C Rechargeable Battery
- LED Status Display
- Real-Time Battery & LASER Level Indicators
- 5-Section Telescopic Pointer
- Precision Capacitive Touch Tip Support
- Lanyard for Ease Handling
- Integrated Media and Slides Control
- Plug and Play USB Receiver

Specification :

Connectivity	: USB Receiver (2.4GHz)
LASER Emitter Class	: Class 3R
LASER Color	: Red
Wavelength	: 630 - 650nm
No. of Buttons	: 6
Input Power	: DC 5V=1A
Charging Time	: 3h
Max. Output Power	: <5mW
Product Dimension	: 2.2 x 2.2 x 19.5 cm (W x D x H)

Product Dimension (Extended)	: 2.2 x 2.2 x 65 cm (W x D x H)
Net Weight	: 60g

Package Contents :

Presentation Pointer	: 1 U
USB Receiver	: 1 U
Type-C Cable	: 1 U
Drawstring Pouch	: 1 U
Lanyard	: 1 U
QR Code Guide	: 1 U

Product Description :



Button Functions :

Button	Function
LASER	Press and hold to enable LASER point. Press and hold the Page Up button simultaneously to increase the laser brightness. Press and hold the Page Down button simultaneously to decrease the laser brightness. LASER brightness level can be viewed on the LED Display.
Page Up	Press the button to slide page up. Press and hold to enter/exit full screen.
Page Down	Press the button to slide page down. Press and hold to enter/exit black screen.
Annotation	Annotation function: In full-screen mode, Long press to enter/exit annotation. Double-click to clear the annotation. In annotation mode, long press the Volume- Button to change to an eraser to clear annotations. Long press the annotation button again to return to annotation. Hyperlink function: In full-screen mode, single click to jump to hyperlinks. In full-screen mode, press Volume+ Button and Volume- Button simultaneously to open hyperlinks. In hyperlink mode, long press the Volume+ button to switch windows.
Volume+	Press to increase the volume. Press and hold to switch windows.
Volume-	Press to decrease the volume

Instruction for Use :

Insert the USB Dongle into the computer with USB, Open the PPT/Keynote/PDF file at same time, OK, to start the demonstration. The LED Indicator flashes green whenever a function is performed.

Note: The Mac system only supports page up and page down functions in Keynote software.

Charging Instruction :

Connect the device to a 5V 1A DC adapter through Type-C port. Battery level is displayed on the LED Display.



ISO 9001:2015 Certified Company
Since 2001 | www.iball.co.in