

# **DHUN180**

Portable BT Speaker



## **User Manual**

*Designed For Excellence.*

[www.iball.co.in](http://www.iball.co.in)

Thank you for choosing **DHUN 180 portable speaker**. Please read the user manual carefully before operation and save this user manual for further reference.

**Note :**

- *Please charge the product with power adapter output rated voltage of DC 5V/9V (2A Max.)*
- *Avoid self-disassembly of the speaker, Kindly approach our service team with reference to the following link for service support :*

**Warranty Policy**

## Features :

- 50Watts RMS
- Max. 5h\* Playtime
- Supported Inputs (BT | USB | mSD | AUX)
- True Wireless Duo (TWS)
- Dual Dynamic Drive
- Control Hub For Media & Volume
- Metal Carry Handle
- 7 RGB Light Mode
- Type - C Charging Port
- Built - in Rechargeable Battery
- Dual Preset EQ (Indoor | Outdoor)
- Fabric Mesh
- Call Function

## Specification :

Model No.	: DHUN 180
Output Power (RMS)	: 50W
BT Version	: v5.3
Driver Size	: Full Range - 6.35 cm x 2
Speaker Impedance	: Full Range - 4Ω
Frequency Response	: 20Hz to 20KHz
S/N Ratio	: ≥66dB
Max Supported USB/mSD memory size	: 32GB
Supported Audio formats	: mp3


Charging Time	: 4h
Playback Time	: 5h*
Product Dimension	: 30.5 x 12.5 x 19.5 cm (W x D x H)
Net Weight	: 1.9 Kg

*\*At 70% volume and LED Off, Playtime will vary based on the user , music preference and volume level.*

**Package Contents :**


Speaker	: 1 U
Charging Cable	: 1 U
Audio Cable	: 1 U
QR Code Guide	: 1 U

## BUTTON DESCRIPTION:



1. **POWER BUTTON** : Long press the power button to power ON/OFF the speaker.
2. **PLAY/PAUSE** : Short press to play or pause the track. Long press the button to get into TWS mode
3. **BACKWARD/VOLUME DOWN** : Short press to decrease the volume. Long Press to move to the previous track.
4. **FORWARD/VOLUME UP** : Short press to increase the volume. Long press to move to the next track.
5. **MODE BUTTON** : Short press the mode button to switch to BT mode when the speaker is in USB or AUX mode.
6. **EQ BUTTON** : Short press the EQ button to switch between two EQ modes.

## PORT DESCRIPTION :



1. USB Port
2. Micro SD Card
3. AUX Port
4. Type-C Charging Port
5. Charging Indicator

## CONNECTIVITY PROCEDURE:

### BT Mode:

Switch on the speaker to BT mode, Scan for nearby BT devices in your device. Tap on iBall Dhun180 to connect.

### USB Mode:

Insert the USB Drive to the USB port, the speaker will detect the USB Drive and the audio file will be played automatically.

### AUX-IN:

The speaker can be connected to an device a AUX cable (3.5 mm) Connect the

one end of the cable to the speaker & connect the other end of the cable to an audio source. The tracks from the audio source can be heard through the speaker.

### **Call Function:**

- Connect the Speaker to your mobile device.
- Short press the Play/pause button to attend the call and to decline the call.
- Long press the Play/Pause button to reject the call.

### **TWS Function:**

Turn On the Two iBall Dhun 180 speakers you want to pair. Long Press the Play/Pause button to get into TWS Mode make sure the other speaker is in BT Mode. After few seconds, both the speakers will be connected successfully. Now, search for nearby device in your mobile and tap the BT name "iBall Dhun180" to connect.

### **Note:**

*Requires Two iBall Dhun 180 speakers for using TWS feature.*

### **Charging Instruction:**

Connect the charging cable to a DC5V/9V adaptor and connect the other end to the speaker. While charging a Red LED will glow and the LED goes OFF once the speaker is fully charged.



ISO 9001:2015 Certified Company  
Since 2001 | [www.iball.co.in](http://www.iball.co.in)