

# **QWERTY S600**

HYBRID WIRELESS KEYBOARD



**Ba11**



## **User Manual**

*Designed For Excellence.*

[www.iball.co.in](http://www.iball.co.in)

Thank you for choosing **iBall QWERTY S600 Hybrid Wireless Keyboard**. Please read the user manual carefully before operation and save this user manual for further reference.

**Note :**

- *Please charge the product with power adapter output rated voltage of DC 5V.*
- *Please do not attempt to disassemble this product yourself, as it will result in voiding the warranty. For expert assistance, please contact our support team at 84400 45005 or [feedback@iball.co.in](mailto:feedback@iball.co.in)*

To review our complete warranty terms and conditions, please click the link below

[\*\*\*View Warranty Policy\*\*\*](#)

To find your nearest authorized service center, please click the link below

[\*\*\*Find a Service Center\*\*\*](#)

## Features :

- Volume Control Knob
- 2.4GHz + 2 BT + Wired Modes
- Type-C Rechargeable Keyboard
- Compact Full-Size 99-Key Layout
- Multi-OS Compatible
- 15 RGB Backlit Adjustment
- 19 Anti Ghosting Keys
- 12 Media Keys
- 2-Level Retractable Stand
- WIN-MAC Toggle Switch
- Wired | BT | 2.4 GHz Mode Toggle Switch

## Specifications :

|                           |                                    |
|---------------------------|------------------------------------|
| Connectivity Interface    | : 2.4GHz + 2 x BT +<br>Wired Modes |
| Compatible OS             | : Windows   MAC<br>Linux           |
| No. of Keys               | : 99                               |
| No. of Multimedia Keys    | : 12 (Integrated)                  |
| No. of Anti-Ghosting Keys | : 19                               |
| Power Consumption         | : DC 5V, 1A (Max.)                 |
| Keystrokes Life           | : 10 Million Cycles                |
| Wireless Range            | : 10 meter<br>(Without Obstacles)  |
| Cable Length              | : 1.5 meter                        |

|                   |                                       |
|-------------------|---------------------------------------|
| Product Dimension | : 37.6 x 13.5 x 2.4 cm<br>(W x D x H) |
| Net Weight        | : 631 g                               |

**Package Contents :**

|                 |       |
|-----------------|-------|
| Keyboard        | : 1 U |
| USB Receiver    | : 1 U |
| Connector Cable | : 1 U |
| QR Code Guide   | : 1 U |



**Product Descriptions :**

Charging Indicator



Volume Control Knob



Mode Toggle Switch  
(OFF | BT | 2.4G)

Type-C Charging Port

OS Toggle Switch  
(WIN | MAC)

## Instructions for Use :

### Wired Mode :

Connect the provided Connector Cable from the PC/Laptop to the keyboard.

### Wireless Modes :

#### 2.4GHz Mode :

- Connect the dongle provided with the keyboard to the PC/Laptop and switch the keyboard to **2.4GHz Mode** using the **Toggle Switch** on the Top of the keyboard.
- The Charging Indicator starts **blinking** when **2.4G Mode** is selected in the **Mode Toggle Switch** and turns off once connected successfully.

#### BT Pairing Mode :

- Toggle the switch to **BT Mode**.
- Press and hold **Fn + BT1** or **Fn + BT2** to select the corresponding BT mode.
- The **Num Lock** indicator starts **blinking** when **BT1** is selected and the **Caps Lock** Indicator starts **blinking** when **BT2** is selected indicating that the keyboard is in **discovery (pairing) mode**.



- Open the BT Settings in the PC | Laptop and scan for the keyboard name **iBall BT1 & iBall BT2** respectively and pair it. Once Connected, The indicator will stop blinking.

## 2 BT Connection and Switching between the Connections :

- The keyboard supports up to **2 BT Connections**, which can be switched as per usage. For instance, you can connect your, Laptop or other BT supported device on **BT1 / BT2** respectively.
- Once connected to the devices, you can press the **FN+BT1 / FN+BT2** button (short press) to switch among the **2 BT Connections**.
- This helps you to keep the **keyboard connected to 2 devices** in the same time and allows you to switch between them as per requirement.

## Multimedia Functions :

### To Switch between Windows & MAC Modes :

Switch the keyboard to **Windows or Mac OS Mode** using the **OS Toggle Switch** on the top of the keyboard.



## Multimedia Key Shortcuts :

| Windows                 |                    |
|-------------------------|--------------------|
| Multimedia Key Shortcut |                    |
| FN+F1                   | Open the Player    |
| FN+F2                   | Volume-            |
| FN+F3                   | Volume+            |
| FN+F4                   | Mute               |
| FN+F5                   | Stop               |
| FN+F6                   | Previous Song      |
| FN+F7                   | Play / Pause       |
| FN+F8                   | Next Song          |
| FN+F9                   | Mail               |
| FN+F10                  | Homepage           |
| FN+F11                  | Lock PC            |
| FN+F12                  | Instant Calculator |
| FN+I                    | PRTSCR             |
| FN+O                    | SCRLK              |
| FN+P                    | PAUSE              |
| FN+K                    | HOME               |

| MAC                     |                                    |
|-------------------------|------------------------------------|
| Multimedia Key Shortcut |                                    |
| F1                      | Decrease Brightness of the Display |
| F2                      | Increase Brightness of the Display |
| F3                      | (OPT+CMD+D) Show / Hide Dock       |
| F4                      | (CMD+SPACE) Spotlight Search       |
| F5                      | Talk to SIRI                       |
| F6                      | (CMD+SHIFT+4) Screen Shot          |
| F7                      | Previous Song                      |
| F8                      | Play / Pause                       |
| F9                      | Next Song                          |
| F10                     | Mute                               |
| F11                     | Volume-                            |
| F12                     | Volume+                            |

## Function Key Combinations & LED Effects Control :

| Function Key Combination |                                |
|--------------------------|--------------------------------|
| FN+↑                     | Increase RGB light brightness  |
| FN+↓                     | Decrease RGB light brightness  |
| FN+←                     | Decrease RGB light speed       |
| FN+→                     | Increase RGB light speed       |
| FN+1                     | BT1                            |
| FN+2                     | BT2                            |
| FN+Enter                 | Switching 15 RGB light effects |
| FN+Backspace             | Turn the RGB lights Off/ On    |

## Volume Control Knob :

- Rotate the Knob **Clockwise** to increase volume.
- Rotate the Knob **Anti-Clockwise** to decrease volume.
- Press the **Button** to mute/unmute volume.



ISO 9001:2015 Certified Company  
Since 2001 | [www.iball.co.in](http://www.iball.co.in)