GLIDRS290
Wireless Mouse

i
Ball

User Manual

Thank you for choosing **iBall Glidr S290 Wireless Mouse**. Please read the user manual carefully before operation and save this user manual for further reference.

Note :

- *Please charge the product with power adapter output rated voltages DC 5V*

- *Avoid self-disassembly of the Keyboard, Kindly approach our service team with reference to the following link for service support :*

Warranty Policy

Features :
- 2.4GHz & BT Modes
- 1600 DPI Switchable
- Ambidextrous
- Type-C Rechargeable Mouse
- 3-Level DPI Shift
- 4-Button Control
- Auto Sleep Mode
- High Precision

Specification :

Connectivity	: 2.4GHz + BT
Resolution	: 800 | 1200 | 1600 DPI
Sensor	: Optical
No. of Buttons	: 4
Button Life	: 3 Million Cycles
Wireless Range	: 10 meter (Without Obstacles)
Product Dimension	: 6.3 x 10.8 x 4 cm (W x D x H)
Net Weight	: 78g

Package Contents :

Mouse	: 1 U
USB Nano Receiver	: 1 U
USB A Cable to Type C	: 1 U
QR Code Guide	: 1 U

Product Description :

Left Click

Scroll Wheel

Right Click

DPI Button

Mode Switch Button

ON/OFF Toggle

Connectivity Procedure

2.4 GHz Wireless Mode:

Step 1   : Plug the Nano receiver into the PC.

Step 2   : On the rear of the mouse, press the mode switch to enter into the 2.4 GHz mode.

Step 3   : The Red LED light emits for a few seconds and it turns off once it has been paired with the device.

BT Mode:

Step 1   : On the rear side of the mouse, press the mode button to enter BT mode. Now press and hold the mode button for 3 secs to enter BT discovery.

Step 2   : Open the BT menu on your BT device and search for the BT name "**iBall S290**".

Step 3   : The Green LED light emits for a few seconds and it turns off once it has been paired with the device.

Charging:

Connect the mouse using a Type-C charger. While charging, the LED at the back of the mouse emits a red light and turns off once the mouse is fully charged.